

Perfect Combination Of Size & Innovative Functions!

Ergonomic, Magnetic Hanger, Probe Holders, Tilt stand, Battery & Fuses Access Cover... User-Oriented
PC-Comm, Bar-graph, Beep/Jack, Crest (Peak), Rec (Min Max), Relative, Backlit... Full-Features!
AutoCheck+LoZ, EF-Detection, Capacitance, Line Level Hz, Temperature... Full-Functions!



CE

**BM250 Series
Practical Multimeters**

BRYMEN[®]
BRIGHT PEOPLE'S CHOICE
<http://www.brymen.com>



● **BM257**



● **BM255**



● **BM252**



● **BM251**

257	255	252	251	FUNCTIONS & FEATURES
●	●	●	●	3-5/6 Digits 6,000 Counts Large Easy To Read LCD Display
●	●	●	●	Fast Measurements, 5/Sec; Fully Auto-Ranging
●	●	●	●	24 Segment Analog Bar-graph Updates 40/Sec
●	●	●	●	0.2% High Basic DCV Accuracy
●	●	●	●	Auto Power Off
●	●	●	●	Optional Purchase RS232C+USB Cables & Software For Win98/2k/xp/Vista
●	●	●	●	True RMS AC Conversion
●	●	●	●	AutoCheck™ Feature (Automatic DCV, ACV & Ohms Selection)
●	●	●	●	Lo-Z Volts To Drain Ghost Voltages (AutoCheck™ Feature)
●	●	●	●	Record Max/Min Readings, Auto-Ranging
●	●	●	●	Crest (Peak Hold) Max/Min Readings
●	●	●	●	Back-Lighted Large Easy To Read LCD Display
●	●	●	●	Data Hold
●	●	●	●	Relative Zero Mode
●	●	●	●	Non-Contact EF-Detection (NCV)
●	●	●	●	Probe-Contact EF-Detection For More Precise Indication Of Live
●	●	●	●	Beep-Jack™ Input Warning Against Improper A-Terminal Plug In
●	●	●	●	DCV 0.01mV To 1000V
●	●	●	●	ACV 0.01mV To 1000V
●	●	●	●	DCA 0.1 μ A To 8A (15A for 30 sec. max with 5 minutes cool down interval)
●	●	●	●	ACA 0.1 μ A To 8A (15A for 30 sec. max with 5 minutes cool down interval)
●	●	●	●	Ohms 0.1 Ω To 60M Ω
●	●	●	●	Capacitance 60.00nF To 3000 μ F
●	●	●	●	Type-K Temperature Readings -50°C To 1000°C
●	●	●	●	Line Level Frequency 10.00Hz To 10.00kHz
●	●	●	●	Logic Level Frequency 5.00Hz to 1.000MHz
●	●	●	●	Diode Tester
●	●	●	●	Rugged Fire Retarded Casing
●	●	●	●	Replaceable Protective Holster With Probe-Holders & Tilt-Stand
●	●	●	●	Optional Purchase Magnetic Hanger
●	●	●	●	Batteries And Fuses Access Door
●	●	●	●	600V General (Ohm, Capacitance ... etc.) Input Protection
●	●	●	●	Transient Protection Up To 6kV 1.2/50 μ s Lightning Surge
●	●	●	●	LVD Meets EN61010-1 CAT II 1000V, CAT III 600V & CAT IV 300V
●	●	●	●	EMC EN61326-1:2006 (EN55022, EN61000-3-2/3 & EN61000-4-2/3/4-5/6-8/11)

Right Size, High Safety and Nice Features !

Equipped With EF-Detection For Live Lines Identification !

Beep-Jack™ Guards Against Improper Plug In !

HIGH SPEED AUTO-RANGING
SHORTENS THE TIME TO TEST
AND INCREASES THE EASE OF USE

AUTO & MANUAL-RANGING
AUTO-RANGING WITH
MANUAL-RANGING OVERRIDE

DISPLAY BACKLIGHT
FOR EASY VIEWING IN THE DARK

FUNCTION SELECTION
TOGGLE CONVENIENTLY BETWEEN
PRIMARY & SECONDARY FUNCTIONS

CAPACITANCE
UP TO 3000 μ F WITH 600V PROTECTION;
AUTO-RANGING

MAX MIN RECORD
RECORD MAX and MIN
READINGS; AUTO-RANGING

HIGH IMPEDANCE VOLTAGE
1000VAC/DC MEASURING CAPABILITIES;
HIGH INPUT IMPEDANCE FOR
LOAD SENSITIVE CIRCUITS

AUTOCHECK™ FEATURE
AUTOMATIC SELECTION OF
LoZ DCV, LoZ ACV & OHMS

GHOST-VOLTAGE-BUSTER
LoZ DRAINS GHOST/ STRAY VOLTAGES
LEAVING ONLY HARD SIGNALS
ON METER READINGS

DIODE TEST
FOR CHECKING DIODES
AND RECTIFIERS

FAST AUDIBLE CONTINUITY
FOR QUICK OPEN-SHORT TESTS
ON SWITCHES, FUSES, AND WIRES

BEEP-JACK™ AUDIBLE WARNING
BEEPS AGAINST IMPROPER A-TERMINAL
PLUG IN. DECREASES RISKS OF DAMAGE

PROTECTIVE HOLSTER
WITH HOLDERS FOR PROBE STORAGE
AND "THIRD HAND" FEATURE
REPLACEABLE & WASHABLE

PC INTERFACE CAPABILITY
OPTIONAL PURCHASE RS232C+USB CABLES
WITH DATA RECORDING PC SOFTWARE
FOR WIN98/NT/42K/XP/VISTA

RUGGED & DURABLE
HIGH-IMPACT FIRE-RETARDED ENCLOSURE
FOR REINFORCED SAFETY & DURABILITY

ASIC TECHNOLOGY
MORE FUNCTIONS & FEATURES
AT AFFORDABLE PRICES

TRUE RMS MEASUREMENTS
FOR NON-SINUSOIDAL WAVEFORMS
OF AC VOLTAGES & AC CURRENTS

LARGE 6000 COUNTS LCD DISPLAY
5/SEC FAST NOMINAL UPDATE RATE

HIGH ACCURACY
0.2% BASIC DCV ACCURACY

ANALOG BAR-GRAPH
FAST UPDATE RATE 40/SEC

LOGIC LEVEL Hz (mV FUNCTION)
MEASURES HI FREQUENCY
LOGIC SIGNALS

LINE LEVEL Hz (V FUNCTION)
MEASURES NOISY HIGH VOLTAGE
ACV FREQUENCIES

EF-DETECTION
BOTH NON-CONTACT (NCV) &
SINGLE-PROBE VOLTAGE DETECTION
FOR IDENTIFYING LIVE LINES

DATA HOLD
FREEZES THE DISPLAYING
READING FOR LATER VIEW

CREST (PEAK HOLD)
CAPTURES INSTANTANEOUS
+PEAK & -PEAK

TYPE-K TEMPERATURE
SELECTABLE °C & °F READINGS

AUTO-POWER-OFF
TO EXTEND BATTERY LIFE

ERGONOMIC STREAMLINE DESIGN
FITS COMFORTABLY IN ONE'S HAND

TRANSIENT PROTECTION
UP TO 6kV 1.2/50 μ s LIGHTNING SURGE;
SUPERB PROTECTION FOR SERIOUS USERS

EMC
MEETS EN61326-1:2006
(EN55022, EN61000-3-2/3 &
EN61010-4-2/3-4/5-6/8-11)

LVD SAFETY
MEETS EN61010-1 2ND EDITION
CAT II 1kV, CAT III 600V & CAT IV 300V

BM257, BM255, BM252 & BM251 GENERAL SPECIFICATION

Display: 3-5½ digits 6,000 counts

Update Rate: 5 per second nominal

24 Segments Bar Graph: 40 per second max

Operating Temperature: 0°C to 40°C

Relative Humidity: Maximum relative humidity 80% for temperature up to 31°C decreasing linearly to 50% relative humidity at 40°C

Altitude: Operating below 2000m

Storage Temperature: -20°C - 60°C, < 80% R.H. (with battery removed)

Temperature Coefficient: Nominal 0.15 x (specified accuracy) / °C @ (0°C - 18°C or 28°C - 40°C), or otherwise specified

Sensing:

BM257, BM252, & BM255: Average sensing

BM251: True RMS sensing

Resolution Degree: 2

Safety: Double insulation per IEC61010-1 2nd Ed., IEC61010-1 2nd Ed., UL61010-1 2nd Ed. & CAN/CSA C22.2 No. 61010.1-0.92 to Category II 1000V, CAT III 600V and CAT IV 300V AC & DC

Electrical Specification

Accuracy is given as +/- (% of reading digits + number of digits) or otherwise specified @ 23°C +/- 5°C and less than 75% R.H.

True RMS model BM257 ACV & ACA accuracies are specified from 5% to 100% of range or otherwise specified. Maximum Crest Factor <3:1 at full scale & <6:1 at half scale, and with frequency components fall within the meter specified frequency bandwidth for non-sinusoidal waveforms

AC Voltage

RANGE	Accuracy
50Hz - 400Hz	
60.00mV, 600.0mV	1.0% + 5d
6.000V, 60.00V, 600.0V, 1000V	
CMRR: >60dB @ DC to 60Hz, Rs=1kΩ	
Input Impedance: 10MΩ, 50 pF nominal	

AutoCheck™ ACV (BM255 & BM257 only)

RANGE	Accuracy
50Hz/60Hz	
1.000V - 1000V	1.4% + 5d

AutoCheck™ Lo-Z ACV Threshold: > 1V nominal
AutoCheck™ Lo-Z ACV Input Impedance: Initially approx. 2.5kΩ, 120pF nominal; Impedance increases abruptly within a fraction of a second as display voltage is above 50V (typical). Ended up impedances vs display voltages typically are:

15kΩ @ 100V
100kΩ @ 300V
250kΩ @ 600V
375kΩ @ 1000V

DC Voltage

RANGE	Accuracy
60.00mV, 600.0mV	0.2%+3d
6.000V, 60.00V, 600.0V, 1000V	
NMR: > 60dB @ 50Hz/60Hz CMRR: > 100dB @ DC, 50Hz/60Hz; Rs=1kΩ Input Impedance: 10MΩ, 50 pF nominal	

AutoCheck™ DCV (BM255 & BM257 only)

RANGE	Accuracy
1.000V - 1000V	1.3% + 3d

AutoCheck™ Lo-Z DCV Threshold: > +1.0VDC & < -1.0VDC nominal

AutoCheck™ Lo-Z DCV Input Impedance: Initially approx. 2.5kΩ, 120pF nominal; Impedance increases abruptly within a fraction of a second as display voltage is above 50V (typical). Ended up impedances vs display voltages typically are:

15kΩ @ 100V
100kΩ @ 300V
250kΩ @ 600V
375kΩ @ 1000V

OHM

RANGE	Accuracy
600.0Ω, 6.000kΩ, 60.00kΩ, 600.0kΩ	0.5%+4d
6.000MΩ	0.7%+4d
60.00MΩ	1.2%+4d

Open Circuit Voltage: 0.45VDC typical

Transient Protection: 6.5kV (1.2/50µs surge)

Terminals (to COM) Measurement Category:
V: Category II 1000V, CAT III 600V and CAT IV 300V AC & DC.

mA_{AC}: Category III 500Vac and 300Vdc.

A: Category III 600Vac and 300Vdc.

E.M.C.: Meets EN61326-1:2006 (EN55022,

EN61000-3-2, EN61000-3-4, EN61000-4-2,

EN61000-4-3, EN61000-4-4, EN61000-4-5,

EN61000-4-6, EN61000-4-8, EN61000-4-11)

In an RF field of 3V/m.

Capacitance function is not specified

Other function ranges:

Total Accuracy = Specified Accuracy + 100 digits

Performance above 3V/m is not specified

Overload Protection:

mA: 10A/600Vac or 15A/600Vac, IR 100kA @600Vac

V: 1050 Vrms, 1450 Vpeak

AutoCheck™ mV, OHM & others: 600 Vrms

Low Battery: Below approx. 2.3V

Power Supply: 1.5V AAA Size battery X 2

Power Consumption (typical): 3.5mA

AP0 Consumption (typical): 10µA

AP0 Timing: idle for 34 minutes

Dimension: 161*80*50mm L*W*H (With Holder)

Weight: Approx. 340 gm (With Holder)

Special Features: AutoCheck™ V & Ω (BM255 & BM257 only); Auto-ranging MAX/MIN Record (BM255 & BM257 only); Crest mode (Peak Hold; BM255 & BM257 only); Backlighted display (BM255 & BM257 only); Auto-ranging Zero Relative mode; Display Hold; EF-Detection (NCV); Interface capabilities with PC computer; input warning detection

Accessories: Test lead pair; Batteries installed; User's manual; BKP90 banana plug type-K thermocouple (BM252, BM255 & BM257 only)
Optional purchase accessories: BRUA-20X USB interface kit; BMH-01 Magnetic hanger; BKB32 banana plug to type-K socket plug adaptor

AutoCheck™ OHM (BM255 & BM257 only)

RANGE	Accuracy
00.00Ω - 60.00kΩ	1.2% + 10d

Open Circuit Voltage: 0.45VDC typical
AutoCheck™ OHM Threshold: < 10MΩ nominal

◀ Audible Continuity Tester

Audible Threshold: Between 10kΩ and 80kΩ

Response time: 32ms

↔ Diode Tester

RANGE	Accuracy
1.000V	1.0% + 3d

Test Current: 0.56mA typically
Open Circuit Voltage: < 1.8VDC typically

↔ Capacitance (BM252, BM255 & BM257 only)

RANGE	Accuracy
60.00nF, 600.0nF	2.0%+5d
6.000µF, 60.00µF, 600.0µF	1.5%+5d
3000µF	2.0%+5d

Accuracies with film capacitor or better

Temperature (BM252, BM255 & BM257 only)

RANGE	Accuracy
-50 °C - 1000 °C	0.3% + 3d
-58 °F - 1832 °F	0.3% + 6d

K type thermocouple range & accuracy not included

DC Current

RANGE	Accuracy	Burden Voltage
600.0µA, 6000µA	0.5%+3d	0.10 mV/uA
60.00mA, 600.0mA		1.7 mV/mA
6.000A, 08.00A		0.02V/A

*8A continuous, >8A to 15A for 30 sec. max with 5 minutes cool down interval

AC Current

RANGE	Accuracy	Burden Voltage
50Hz - 400Hz		
600.0µA, 6000µA	1.0%+3d	0.10 mV/uA
60.00mA, 600.0mA		1.7 mV/mA
6.000A, 08.00A		0.02V/A

*8A continuous, >8A to 15A for 30 sec. max with 5 minutes cool down interval

CREST Mode (BM255 & BM257 only)

Accuracy: Specified accuracy plus 150 digits for changes > 5ms in duration.

RECORD Mode (BM255 & BM257 only)

Accuracy: Specified accuracy plus 100 digits for changes > 100ms in duration.

Logic Level Hz (mV function)

RANGE	Sensitivity (square wave)
5.00 Hz - 500.0 kHz	3 Vpeak
5.00 Hz - 1.000 MHz	5 Vpeak

Accuracy: 0.03%+2d

Hz (Line) @ ACV, DCV, Current & AutoCheck™

Function	Sensitivity (Sine RMS)	Range
6V	0.4V	10Hz - 10kHz
60V	4V	10Hz - 50kHz
600V	40V	10Hz - 50kHz
1000V	400V	45Hz - 1kHz
600µA	40µA	10Hz - 10kHz
6000µA	400µA	10Hz - 10kHz
60mA	4mA	10Hz - 10kHz
600mA	40mA	10Hz - 10kHz
6A	1A	10Hz - 1kHz
10A	6A	10Hz - 1kHz

Accuracy: 0.03%+3d

Non-Contact EF-Detection

Typical Voltage	Bar Graph Indication
20V (tolerance: 10V - 36V)	-
55V (tolerance: 23V - 83V)	--
110V (tolerance: 59V - 185V)	---
220V (tolerance: 124V - 330V)	----
440V (tolerance: 250V & 1000V)	-----

Indication: Bar-graph segments & audible beep tones proportional to the field strength
Detection Frequency: 50/60Hz
Detection Antenna: Top-right end of the meter
Probe-Contact EF-Detection: For more precise indication of live wires, such as distinguishing between live and ground connections, use the Red (+) test probe for direct contact measurements.



BRYMEN TECHNOLOGY CORPORATION

http://www.brymen.com

TEL: +886 2 2226 3396 (rep)

FAX: +886 2 2225 0025

Copyright © MMVIII B.T.C. All rights reserved

Specifications subject to change without notice

Patents pending. Printed in Taiwan